

Gotharman's Little deFormer



Update 553

Knobs 1 to 8 MIDI CC output limited

Little deFormer had the ability of transmitting a constant stream of MIDI data, when the knobs were used to control external gear. Unfortunately much MIDI gear could not handle this stream, so it caused problems in many cases.

The MIDI CC's output of Little deFormer has now been limited, so every time it has transmitted a MIDI CC, it pauses for 1 MIDI CC.

Furthermore an extra parameter “CCs” has been added to the “COMMON” section. This parameter makes it possible to adjust the MIDI CC rate further down, in case the standard limitation does not solve any problems, you might have with this.

It can be set to:

-On: The new “normal” mode. Little deFormer transmits 1 MIDI CC, and then pauses for one MIDI CC.

-1/2: Little deFormer transmits 1 MIDI CC, and then pauses for 2 MIDI CC's.

-1/4: Little deFormer transmits 1 MIDI CC, and then pauses for 4 MIDI CC's.

-Off: Little deFormer does not transmit MIDI CC's at all.

Sample Quick Record Auto Naming

Another new parameter, Qrec “Name”, has been added to the “COMMON” section. This can be set to:

-Manu: Manual naming mode. This is how it always was, before this update: When you stop Qrec, Little deFormer stops all playback and jumps to the sample naming page, where you can audition, name and save your new sampling.

-Auto: Automatic naming mode. When you stop Qrec with this mode selected, Little deFormer will not stop any playback, and nor will it jump to any specific page. It just stops Qrec, autosaves the new sampling with the name “Qrec (preset number)”, and assigns the new sampling to the last selected sample slot.

How to access the sample Quick Record function:

On LD2:

-Press and hold the “Exit” button, while pushing the “Dec” button (marked on the faceplate as “Qrec”). The “Freeze” LED will flash.

-Push the same button combination, to exit Quick Record again.

On LD Limited Edition and Standard:

-Press and hold the “Exit” button, while pushing the “Freeze” button. The “Freeze” LED will flash.

-Push the same button combination, to exit Quick Record again.

GotharMan's

February

2015